



通常使用時

②

U字型カッター

スライサーは
両方向に使用可

①
ピーラー

③
V字型カッター

⑥
オレンジピーラー

デコレーションカッター使用時

デコレーションカッター

④

⑤
ヘタ取り

スライサー使用時



内側に取扱説明書があります。

原産国：台湾

スーパーピーラー SUPER PEELER

Function 1: Peeling

First, remove the cutter cover. Then, draw the blade slowly over the fruit or vegetable, shown for example in Fig. 1. Because of the special design, very small quantities of peel are removed, making it very economical to use. Always work in one direction and then in the opposite direction, e.g. from top to bottom or from front to back. The peeler works in both directions, and saves cooking preparation time thanks to the serrated double-blade.



Function 2: U-shaped Paring Knife

Hold the extra-fine peeler horizontal to the cucumber, shown for example in Fig. 2. Apply light and even pressure, drawing it across the surface of the cucumber. Always cut towards your body, in the direction of the fiber of the fruit or vegetable. Carefully draw the blade back along the same cut-line and repeat these steps until you have worked all the way around. Using the U-shaped blade, you can create different types of garnishes quickly and easily. TIP: Don't make the spaces between the individual cutlines too big. By keeping the spaces as small as possible, you will achieve a much more professional and flower-like finish. Put a finished radish, for example, into cold water for 25 minutes and be amazed how it curls up to look like a water lily.



Function 3: V-shaped Paring Knife

Hold the handle of the peeler horizontal to the orange, as shown for example in Fig. 3. Draw it with an even pressure across the skin of the fruit. You should only cut from top to bottom, which will give you very fine strips. These strips can be plaited or you can loop them into the same cut-line or into the next one, as shown in Fig. 3. Here, you also have an unbelievable number of design options, just use your imagination! Show your friends and family how creative you can be. They're sure to be impressed!



Function 4: Decorating Cutter

You will find a clip on the back of the peeler. While pressing the U-shaped blade against the front of the peeler with one thumb, press the clip down to open up the decorating cutter completely from the inside of the peeler. Now, insert the pointed end of the blade in the flesh of the fruit, up to half the length of the blade, as shown for example with the pear in Fig. 4. Remove the blade and insert it again approximately 1/2 inch to the side of the first cut. Repeat this process until you have cut all the way around the fruit. Separate the two halves of the pear and you will have created a wonderful crown effect.



Function 5: Citrus End Remover

Remove the decorating cutter completely from the inside of the peeler. Always snap the blade cover back onto peeler blade when not using the citrus end remover on the stem end of the fruit, as shown in Fig. 5. Turn the citrus end remover left and right until you can remove the stem from the fruit. Now, fold the decorating cutter with the citrus end remover back onto the peeler, until the plastic clip clicks back into place.



Function 6: Orange Peeler

Remove the stem end from the orange as described under function 5. Then turn the citrus end remover left after removing the stem end, as shown in Fig. 6, pull the peeler from top to bottom. Turn the orange about 1 1/2 inch and repeat until you have worked your way around the whole fruit. Next pull the peeler through the cut-lines, to easily separate the peel from the



7
機能

⑦ スライサー
⑥ オレンジピーラー
⑤ ヘタ取り
④ デコレーションカッター
③ V字型カッター
② U字型カッター
① ピーラー

スーパーピーラー SUPER PEELER

7つの機能

①ピーラー

独自の構造により、薄く剥くことができます。また、**両方向**に剥くことができるので非常に効率的です。



②U字型カッター

ジャガイモなどの芽取りに最適です。キュウリなどにピーラーを平行に当て少し力を入れて手前に引きます。同じ間隔を開けて繰り返すことで色々な飾り切りが素早くできます。間隔を狭くすると花のようなきれいなカットが出来ます。



③V字型カッター

キュウリなどにV字カッターを軽くあてて引いてください。きれいなV字型の飾り切りが簡単に出来ます。



④デコレーションカット

ピーラーの刃にカバーをつけて手を切らないように保護しご使用ください。持ち手の裏側の黒いフリップを押し、ピーラーの2枚刃がついているU型を下げるとデコレーションカッターが出てきます。この先端をキウイ等に差し込みます。これを繰り返すと素晴らしい王冠カットが手軽に作れます。



⑤ヘタ取り

デコレーションカッターを開きその黒い穴を果物のヘタに当て取れるまで左右に回します。



⑥オレンジピーラー

機能⑤のヘタ取りでオレンジのヘタを取ります。次にV字ナイフ裏側の突起した黒いピーラーでヘタをとったところから真直ぐ下にカットします。4-5cm位オレンジを回して同じようにカットします。これを全体に繰り返しデコレーションカッターでつまんで皮を剥きます。



⑦スライサー

ピーラーの本体を裏返し、付属のスライサーを写真のように差し込むと、前後にスライスできる効率的なスライサーとしてご使用できます。スライサーのフックを器のフチに掛けると安定して作業が出来ます。



本体を裏返して装着、使用します。



使用上のご注意

- *スライサーには保護シートが貼ってありますので剥がしてからお使い下さい。
- *ご使用前に中性洗剤で洗浄してからご使用下さい。
- *用途以外に使用しないで下さい。
- *ピーラーを使用するとき以外は刃にカバーをつけておいて下さい。
- *カッターのカバーをはずすときは指がカッターに触れないようにご注意ください。
- *刃は非常に鋭利なため、カッターで手を傷つけないようにご注意ください。
- *デコレーションカッターは通常は閉じて置いて下さい。
- *刃などに食物が付着した場合は水洗いして乾かして下さい。
- *切れ味が悪くなった場合はご使用をお止めください。怪我をする恐れがあります。
- *子供の手の届かないところに保管して下さい。

材質：本体 ABS樹脂、ステンレススチール
スライサー ステンレススチール
重さ：本体 80g
スライサー 28.6g
サイズ：本体 L15 x W7.5 x H2.5 cm
スライサー L16 x W4 x H1.5 cm
原産国：台湾

総販売元：有限会社プロビジョン
〒224-0032 横浜市都筑区茅ヶ崎中央 41-8
ステーションアリーナ 101
TEL.045-948-0331 FAX.045-948-0332
E-Mail: go3go34@provision.co.jp